NSW GOVERNMENT

ELECTRONICALLY MONITORED VESSEL PUMP OUT SYSTEM
OPERATING INSTRUCTIONS

- CONNECT KAMLOCK VALVE TO VESSEL DISCHARGE POINT AND OPEN VALVE AT PUMP END OF HOSE

- LIFT THE COVER ON THE ADJACENT STAINLESS STEEL CABINET MARKED 'PUMP OUT CONTROLS'

- ENTER YOUR PERMIT NUMBER THEN PRESS ENTER

- IF INVALID CODE PRESS '.' TO CLEAR ENTRY

- IF CODE IS VALID DISPLAY WILL READ 'SYSTEM ON WAITING FOR FLOW ANY KEY TO STOP'

- ALLOW UP TO 30 SECONDS FOR FLOW TO START

- ONCE FLOW IS DETECTED THE DISPLAY WILL CONTINUOUSLY UPDATE WITH THE FLOW SUBTOTAL

- FOLLOWING START UP THE VALVE WILL AUTOMATICALLY CLOSE AFTER 2 MINUTES IF NO FLOW IS DETECTED AND THE DISPLAY WILL CHANGE TO 'FLOW STOPPED'

- PRESS ANY KEY OTHERWISE THE DISPLAY WILL AUTOMATICALLY RESET AFTER 2 MINUTES IF NO KEY IS PRESSED

- REMEMBER TO DISCONNECT PUMP OUT HOSE WHEN COMPLETE

- ENSURE CONTROL PANEL COVER IS CLOSED PRIOR TO LEAVING

REPORT BREAKDOWNS TO PH 13 12 36 OR
COMMUTER.WHARVES@TRANSPORT.NSW.GOV.AU

IP-POS-S19   Issue 1   8.5.25

40 Radius